




acerpure beauty

User Manual

HD765-10W
HD765-10A

www.acerpure.com

Copyright © 2024 AcerPure Inc. All Rights Reserved.

Table of Contents

Safety Instructions	02
Product Configuration and Structure	04
Instructions for the Hair Dryer	07
Instructions for Panel Display	08
Maintenance and Cleaning Methods	09
Product Specifications and Company Information	11

Safety Instructions

⊘ means it is
"prohibited"


! means "caution"
is required

! Please read the safety instructions & precautions before using the hair dryer to ensure safe use of this product. Failure to follow the instructions below may result in the risk of fire, burns, explosion, short circuit or electric shock.	! Check whether the voltage is consistent with the indication on the voltage label of this product before use to prevent the machine from burning or triggering a fire.
! Check whether the plug is ruptured or overheated before use, and do not bend, process, pull or twist the cable in order to prevent electric shocks or fires.	⊘ Switch off the power before unplugging the plug after use. Make sure to hold the plug when unplugging and avoid tugging on the cable to avoid damaging the cable and causing electric shocks.
⊘ Do not wind the power cable on the hair dryer, as doing so can easily cause the cable to get damaged or overheat. Should this happen, please cease use immediately.	! Children should be supervised to ensure they do not play with electrical appliances.
⊘ This product is not intended for use by users (including children) with physiological, perceptual, mental ability, experience or knowledge deficiencies unless used safely under the supervision or guidance of the person responsible for their safeties.	⊘ Do not use this product near flammable objects (gasoline, benzene, thinner, gas, hair gel and spray-on hair sprays, etc.).
⊘ Do not use this product near bathtubs, shower equipment, basins and other water containers.	! If there is a need to use this product in the bathroom, make sure to unplug the power plug after use to avoid the danger of electric shock due to contact with water. To protect your safety, it is recommended that you install a residual current device (RCD) with a rated leakage current of not more than 30mA on the power supply circuit in the bathroom. Consult an installer for details.
! Please keep the air inlet and outlet ventilated, and do not insert or block the air vent with foreign objects, or leave the hair dryer on for an extended period of time, or leave this product idle, to prevent the machine from overheating or causing fire.	! Do not use this product for purposes other than blow drying and styling real human hair, including wigs, clothes and shoes, and do not use this product on babies and pets.


⊘ This product may not be repaired or modified by repairers who are not authorized by our company. When abnormalities occur, it must be replaced by authorized repair personnel in order to avoid danger.	⊘ This product only requires external cleaning and maintenance; do not clean the surface with rough cleaning tools, and do not rinse it with water directly.
⚠ If you discovered any abnormalities such as noises of foreign objects shaking, burning or strange odors, please switch off the power immediately, unplug the power plug and contact customer service personnel.	⚠ When using any accessories or mouthpiece accessories, make sure to buckle them onto the machine body properly before switching on the machine to prevent sudden ejection of the mouthpiece and causing injuries.
⊘ The temperatures of the accessories and air outlet are extremely high after the power of the machine is turned on. Do not touch them directly, and wait for the mouthpiece to cool off completely before doing so to avoid possible burns.	⊘ Do not look into the air vent while using the product to avoid dust and other foreign objects from blowing out and causing injuries.
⊘ Do not touch the machine and power cable with wet hands, and it is prohibited to expose the product to water or immerse it in water to prevent short circuiting or electric shocks.	⚠ If the power cable is damaged, it must be replaced by the manufacturer, its service department or personnel with related qualifications to avoid danger.
⚠ When using this product in the bathroom, since it is close to water, please unplug the power plug after use; otherwise, danger may occur even if the power of the hair dryer is switched off.	

Product accessories


1 Main Body




2 Concentrator



3 Diffuser




4 Storage Bag




5 Manual and warranty card



Product Structure




Instructions for the Hair Dryer



1. Turn on the machine: Unfold the handle


When the machine is folded, please unfold the handle below towards the bottom-right as indicated by the arrow.



2. Power button/Wind speed adjustment

- || High Level Wind
- | Medium Level Wind
- Power off

Push the button gently to turn on the machine and adjust the wind speed. To power off the machine, simply push the button to the O position.




3. Temperature adjustment

1. Touch this button gently to adjust the wind temperature, the sequence of the wind temperature adjustment is in the following order: Mild / Warm / Hot / Cool Wind.

AI Hair Care Mode

2. Long-press this button for three seconds to enable AI Hair Care mode. The machine will cycle through cool and warm temperatures automatically. To cancel, simply touch the temperature button once gently.



4. Storage: Fold the handle

After finishing using the machine, please fold the handle below to the upper-left for storage.

Instructions for Panel Display

Temperature Status Display

There are 3 different light display in this bar, each represent Mild / Warm / Hot wind.

AI Hair Care Mode

In this mode, 3 light will flash together until the mode is turn off.



Pinoki Ion Tech

Will always turn on when the machine is on. (Ion tech will active when the machine is on.)



Cool Wind

When the machine is adjusted to cool wind, this light will turn on; when the machine is adjusted to hot air, this light will go off.




Airflow Speed

The lights will be displayed according to the current wind speed; there are a total of two speeds.

Temperature Digits Display




The temperature will be displayed according to the different levels of temperatures set; the AI smart mode and cold air will be displayed according to the actual air outlet temperature.

*Please Note :In AI smart mode or cool air, Display panel will show the real temperature. So it's normal to see the number keep going up or down.



Maintenance and Cleaning Methods

Smart Clean Mode & filter cleaning



1.Smart Clean Mode

After inserting the power plug into the outlet, Long press the temperature button while the power is still off, and push the power button upwards to wind speed I or II simultaneously to activate smart cleaning mode. The machine will use reverse wind pressure to blow the dust towards the air inlet for about 20 seconds to facilitate subsequent cleaning.


Note: To Cancel the clean mode within 20 secs, simply press the temperature button once again could do.

2.Remove the dust on the filter

Rotate the air inlet cover in the anti-clockwise direction, and a remove the dust from the surface of the filter.

Note: If there is water used, please make sure the filter have been dried out before use.

Maintenance for the main body



Main Body

1. This product only requires general external cleaning and maintenance. Simply wipe it with a dry cloth under normal circumstances.
2. If there is dirt that is more difficult to clean, it is recommended to wipe the dirt off with a soft cloth dipped in neutral detergent or soap water, then wipe the machine dry with a clean and soft cloth.
- ① Do not wipe it with thinner, toluene, acidic cleansers, lamp oil, alcohol or chemical cloth in order to avoid discoloration or deterioration.
- ② It is strictly prohibited to wash it with water directly.
- ③ Do not use cleaning tools with rough services.

Before seeking after-sales service

Problem	Possible cause	Solution
Product does not turn on	Is the voltage correct& is the power plug plugged in properly?	Using the wrong voltage may result in overloading and cause damage to the machine. Make sure to refer to the product label and use the correct voltage.
Product wind volume became smaller	Are there too many foreign objects accumulated at the air inlet?	1. Clean the air inlet regularly and keep the air ducts clear, and wait for the temperature to drop before trying to turn on the machine again. 2. If the machine still does not work, please contact the after-sales team.
No hot air is coming out of the product	Too much dust accumulated at the air inlet, causing the temperature to increase and the protection mechanisms of the machine triggered.	1. Clean the air inlet regularly and keep the air ducts clear, and wait for the temperature to drop before trying to turn on the machine again. 2. If the machine still does not work, please contact the after-sales team.
	The temperature inside the machine is temporarily too high, and the safety protection mechanisms were activated to turn off the heating wires temporarily.	Please wait for the machine to cool off properly, then try to turn on the machine again. If there is still no hot air from the machine, please contact the after-sales team.
Something smells bad in the hairdryer?	Is there hair&dust inside the machine that caused strange odors to be generated after heating and burning?	1. Under normal usage, minor foreign objects will be decomposed by heating with the blowing air, and should not affect the usage effect. 2. If the strange odor persists without improvement, or there is abnormal wind temperature & wind speed, please contact the after-sales team.

Product specifications

Product specifications	
Product name	Hair dryer
Product model	HD765-10W / HD765-10A
Rated voltage	220-240V/50-60Hz
Rated power	1350-1600W
Net weight	434g(Main Body Only)
Product dimensions	185mm X 45mm X 175mm(Main Body Only)
Place of origin	China

Company information

acerpure

www.acerpure.com

acerpure